

SHOTTING STAR **TIMING BUTTON PROGRAMS**









2 MINUTES 5 MINUTES 10 MINUTES

RF REMOTE CONTROLLER INSTRUCTIONS FOR SHOOTING STAR

(***IMPORTANT !! -- Please NOTE when using "SHOOTING STAR REMOTE " Press timing setting of shooting star (A- Every minute for shooting star), (B- Every 2 minute for shooting star), (C- Every 5 minutes for shooting star), or (D - Every 10 minutes for shooting star), ***Do Not Press Timimg Setting REMOTE Controller Again -- For at least *** 1 TO 5 Minutes. Due to Controller has been set already. But can be reset AFTER 1 minute to 5 minutes, which will allow you to reset timing of shooting star. Then press A,B,C, or D and look for shooting star to light up as you press remote control for your Timing Mode (A- Every minute for shooting star), (B- Every 2 minute for shooting star), (C- Every 5 minutes for shooting star), or (D - Every 10 minutes for shooting star).